


GLAST Large Area Telescope Calorimeter Subsystem

Thermal-Vacuum Test

Paul Dizon






Thermal-Vacuum Testing

**EM CAL in GRID
environment simulator with
heaters and cold plates**


April 2003



**EM CAL inside thermal shroud
mounted to NRL's South
Thermal Vacuum Chamber**

April 2003






T-VAC Requirements and Traceability

- ❑ CAL module shall be capable of full operational performance over four thermal cycles at temperature extremes
 - *LAT Environmental Specification, LAT-SS-00778*


ENVIRONMENT	LAT-SS-00778	LEVELS TEST ARTICLE
Qualification Temperature	Table 30, Section 11.3	-30°C to +50°C (QM)
Acceptance Temperature	Table 30, Section 11.3	-20°C to +35°C (FM)
Operational Temperature	Table 30, Section 11.3	-5°C (QM and FM)

- ❑ Thermal balance test to demonstrate CAL thermal design







T-VAC Test Flow: Protoflight Test



T-VAC Test Flow: Acceptance Test






T-VAC Pass/Fail Criteria

- ❑ **CAL module must meet the following criteria to successfully complete the thermal-vacuum test requirements**
 - **Test levels are applied in accordance with...**
 - *LAT Environmental Specification, LAT-SS-00778, Section 11.3*
 - *CAL Flight Module Thermal-Vacuum Test Procedure, LAT-PS-04455, Sections 5.3.1, 5.3.2, and 6.1*
 - **No damage is incurred by the CAL module**
 - **Data is acquired and archived; suitable for correlation with thermal model**
 - **Successful post-test CAL functional testing and cosmic muon collection, in accordance with *CAL Comprehensive and Limited Performance Test Definition, LAT-MD-01370***






T-VAC Testing to Date

□ Development Testing

- **Developmental model CAL modules and CDEs successfully tested to beyond qualification levels**
 - LM2 & VM2 Performance Verification Plan (LAT-SS-00937) and Report (LAT-TD-00993)
- **EM CAL Module successfully testing to qualification levels**
 - CAL module Thermal-Vacuum Test Procedure (LAT-PS-01347)
 - Thermal Model Correlation (LAT-TD-02551)
 - CAL module EM Thermal-Vacuum and Thermal Balance Test Report (LAT-TD-04370)
 - Problem with EGSE version of TEM power supply at cold temperatures
- **Thermal balance test performed on EM CAL module**





T-VAC Testing to Date (cont.)

❑ Component Testing (Thermal Cycle)


– AFEE cards

- EEE Parts – all parts screened and approved
- Burn-in (85°C) and 3-temperature testing (-30°C, +25°C, +55°C)

– CDE qualification and acceptance sampling includes thermal cycles


- CDE Qualification Plan (LAT-SS-02236-03): 60 cycles (-30°C to +60°C)
- CDE Acceptance Plan (LAT-SS-02235-06): 25 cycles(-30°C to +60°C)






T-VAC Test Configuration

- ❑ The test specimen shall consist of the following, as documented in the as-built configuration list:
 - **CAL Tower Module (LAT-DS-04536)**
- ❑ Deviations from flight configuration
 - **EM2 TEM-TPS assembly used in place of flight unit**
 - **Cold plate and heaters will maintain EM2 TEM/TPS temperature to $+25^{\circ}\text{C} \pm 10^{\circ}\text{C}$**
- ❑ Note that two modules will be tested at once with duplicate test fixtures in a single T-VAC chamber
 - **FMA and FM18 will be tested alone**






T-VAC EGSE Configuration

- Notes:
1. LVDS harness length shall be limited to 10 meters (~32 feet), unless skew budget dictates shorter length
 2. LVDS harness shall utilize twisted shielded pair, # TBD AWG
 3. Ground and/or terminate unused conductors

LAT-DS-01945-01



REVISIONS			
ZONE	REV	DESCRIPTION	DATE

ITEM	QTY.	PART NO.	DESCRIPTION
1	2	SU1000RT2U	Tripp-Lite UPS 1000VA, 6 outlets, rackmount
2	2	BK1743A-ND	DC Power Supply, 0.35VDC, 5-6A Output
3	2	TBD	CPU & Monitor with ethernet card
4	2	TBD	CAT-5 Ethernet Cable
5	2	TBD	Power Supply to VME <28VDC Harness
6	2	TBD	Command Cable Harness
7	2	TBD	Event Cable Harness
8	2	TBD	VME Crate
9	2	LAT-DS-01946	GASU - TVAC Chamber Interface Cable
10	2	LAT-DS-01947	PDU - TVAC Chamber Interface Cable
11	8	TBD	120VAC Power Extension Cables
12	2	TBD	Power Supply Assembly (PSA)
13	2	TBD	Power Electronics Module (TEM)
14	2 of 18	TBD	Calorimeter Module (CAL)
15	2	TBD2	External TVAC Pigtail
16	2	TBD3	Internal TVAC Pigtail
17	2	LAT-DS-01948	TVAC Chamber - TEM Interface Cable
18	2	TBD2	External TVAC Pigtail
19	2	TBD3	Internal TVAC Pigtail
20	2	LAT-DS-01949	TVAC Chamber - PSA Interface Cable

Gamma-ray Large Area Space Telescope


Thermal Vacuum Test Setup

Drawn by: Kurt R. Smithgall

Date: April 4, 2003

SIZE	FSOM NO	DWG NO	REV
		LAT-DS-01945	01
SCALE	1 : 1	SHEET	1 OF 1


Naval Research Lab
Washington DC



T-VAC Test Flow

- ❑ **Thermal-Vacuum Cycle 1**
 - Bake-out
 - Hot and Cold turn-on
 - 4-hour test temperature soak: comprehensive performance test and muon collection
- ❑ **Thermal-Vacuum Cycle 2**
 - Hot and Cold turn-on (QM only)
 - 4 hour test temperature soak: limited performance test and muon collection
- ❑ **Thermal-Vacuum Cycle 3**
 - Hot and Cold turn-on (QM only)
 - 4-hour test temperature soak: limited performance test and muon collection
- ❑ **Thermal-Vacuum Cycle 4**
 - Hot and Cold turn-on (QM only)
 - 4-hour test temperature soak: comprehensive performance test and muon collection
 - Thermal balance test (QM only)
 - 4-hour operational temperature (-5°C) soak: comprehensive performance test and muon collection





T-VAC Facility Status

☐ **Facility will be ready by Sept. 17 (Oct. 1) test date**

- Large thermal chamber, “Big Blue”
- Medium thermal chamber, “North Chamber”
- Temperature controller
- Data acquisition system set-up
- Thermocouples
- Power supplies


Modifications In Process
Modifications In Process
Undergoing Test
In Process
Available
Available

☐ **Test fixture status**

- Test stand
- Thermal blankets
- Heaters
- Cold plates

Available
Available
Available
Delivery (Sept 15)






T-VAC Known Risks and Limitations

- ❑ **EM2 TEM/TPS has not been qualified at temperature**
 - Temperature limits imposed by EM2 design do not meet test requirements
 - Test procedure controls EM2 TEM/TPS to $+25^{\circ}\text{C} \pm 10^{\circ}\text{C}$
- ❑ **Potential conflict with other flight programs for test facilities**
 - Mitigated by use of one of two available chambers





T-VAC Status

ITEM	STATUS
Requirements	Defined
Pass-Fail Criteria	Defined
Testing to Date	Successful (EGSE issue)
Configuration	Defined
Handling/Installation	Defined
Facility Status	In Process
Test Equipment	In Process
Risks and Limitations	Addressed
Procedure	Configured
Status	On Schedule

